




Parts list

Code

Handle screw (1)	0702	
Non-locking switch	0908	
Dynamic label	1027	
Holder assembly screws	4022	
Brace screws (4)	8317	
Lower half handle (label side)	9401.1	
Upper half handle	9402	
Clips (2)	9404	
Braces (4)	9416	
Motor & gear	9417	
Whisk connection box w/ 3 rings	9418	
Middle gear & axle	9420	
Equipped output shaft w/ 2 gears + 2 pins	9421	
Holder assembly w/ seals & washer+D331	9422	
Whisks (2)	9424	
Complete handle	9431	



Charger and battery
See machine catalogue